



LOW LEVEL DISINFECTION ~ **KNOW YOUR WET TIMES**

Use low & intermediate-level disinfectants on “non-critical” equipment (ex. BP cuffs, wheelchairs) and environmental surfaces (ex. countertops).

Wet surface thoroughly with disinfectant. **Do not wipe dry. Surface must remain wet for required time.** Never use these products on skin; Wear gloves when in contact with product.



SUPER SANI-CLOTH (PURPLE TOP)
WET TIME: 2 MINUTES



SANI-CLOTH AF3 (GREY TOP)
For use on items that may be damaged by products that contain alcohol such as Ultrasound probes
WET TIME: 3 MINUTES



VIREX PLUS
WET TIME: 3 MINUTES

Always spray product onto a cloth, then use the cloth to wet the surface to be disinfected.



BLEACH GERMICIDAL SPRAY
only for Contact Plus Isolation
WET TIME: 3 minutes